R90C-4K-MQ IO-Link Master/Modbus Converter CANNER



Instruction Manual



- · Connects four IO-Link devices and provides access via Modbus RTU interface
- · Rugged design; easy installation with no assembly or individual wiring required
- 5-pin M12 male quick-disconnect connector
- Four 4-pin M12 female quick-disconnect connectors
- Built-in indication for four IO-Link master ports
- Built-in indication for Modbus RTU connection status
- Rugged over-molded design meets IP65, IP67, and IP68

Models



Overview

The R90C 4-Port Converter connects to four IO-Link devices and provides access to IO-Link data and functionality via a Modbus RTU connection.

Modbus registers allow for access to both IO-Link devices and their functions:

- Process Data In
- Process Data Out
- Connected device information
- ISDU data
- Discrete I/O configuration
- IO-Link events
- Data storage
- SIO mode

For more information, see p/n 221399 IO-Link to ModBus Converter - Device Register Map.

Status Indicators

The R90C-4K-MQ IO-Link Master/Modbus Converter has matching RGB LED indicators on both sides for each IO-Link device port to allow for installation needs and still provide adequate indication visibility. There is also an Amber LED indicator on both sides of the converter, which is specific to the Modbus communication.

Figure 1. R90C 4-Port Converter status indicators – front and back





IO-Link Device Port 1, 2, 3, and 4 RGB LEDs		Modbus Communication Amber LED		
Indication	Status	Indication	Status	
Off	Deactivated port	Flashing Amber (4 Hz)	Modbus communications are active	
Flashing Green	Waiting for IO-Link device	Solid Amber (2 seconds) to Off	Modbus communications are lost after connection	
Solid Green	IO-Link device is connected	Solid Amber (2 seconds) to Flashing	Modbus communications momentarily lost, but then	
Flashing Red	Validation Error	Amber (4 Hz)	reestablished	
Solid Yellow	Signal high in SIO-mode	Solid Amber	Modbus communications are intermittent, or communications error occurs more frequently once every 2 seconds	
Solid Blue	Processor communication error	Off	Modbus communications are not present	

Installation Instructions

Mechanical Installation

Install the R90C 4-Port Converter to allow access for functional checks, maintenance, and service or replacement.

All mounting hardware is supplied by the user. Fasteners must be of sufficient strength to guard against breakage. Use of permanent fasteners or locking hardware is recommended to prevent the loosening or displacement of the device. The mounting hole (4.5 mm) in the R90C 4-Port Converter accepts M4 (#8) hardware. See the figure below to help in determining the minimum screw length.



 \wedge

CAUTION: Do not overtighten the R90C 4-Port Converter's mounting screw during installation. Overtightening can affect the performance of the R90C 4-Port Converter.

Wiring

Port 1, 2, 3, and 4 – Female	Pin	Signal Description
	1	18 V DC to 30 V DC
2	2	I/Q (digital in-out)
1 1 - [3	Ground
4 3	4	C/Q (communications/digital in-out)

Comm Port – Male	Pin	Signal Description
	1	18 V DC to 30 V DC
	2	RS485/D1/B/+
	3	Ground
• 4	4	RS485/D0/A-
3 5	5	Banner 1-wire

Specifications

Voltage Input Range

18 V DC to 30 V DC

Input Power 24 V DC at 4 A

Output Power

24 V DC at 100 mA + 200 mA/port = 900 mA maximum

Supply Protection Circuitry

Protected against reverse polarity and transient voltages

Leakage Current Immunity

400 µA

Indicators

RGB1: IO-Link Port 1 Status RGB2: IO-Link Port 2 Status RGB3: IO-Link Port 3 Status RGB4: IO-Link Port 4 Status Amber: Modbus Communications

Connections

(4) Integral 4-pin M12 female quick disconnect(1) Integral 5-pin M12 male quick-disconnect connector

Construction

Coupling Material: Nickel-plated brass Connector Body: PVC translucent black

Vibration and Mechanical Shock

Meets IEC 60068-2-6 requirements (Vibration: 10 Hz to 55 Hz, 0.5 mm amplitude, 5 minutes sweep, 30 minutes dwell) Meets IEC 60068-2-27 requirements (Shock: 15G 11 ms duration, half sine wave)

Environmental Ratings

For Indoor Use Only IP65, IP67, IP68, UL Type 1

Operating Conditions

-40 °C to +70 °C (-40 °F to +158 °F) 90% at +70 °C maximum relative humidity (non-condensing) **Storage Temperature:** -40 °C to +80 °C (-40 °F to +176 °F)

IO-Link Baud Rates

COM1: 4.8 kbps COM2: 38.4 kbps COM3: 230.4 kbps

Compliant Standards

IO-Link interface and System Specification v 1.1.2 IO-Link Test Specification v 1.1.2

Master Communication Protocol

RS485 – Modbus RTU

Digital Inputs (SIO [DI] Mode)

Input Current: 5 mA typical ON Voltage/Current: 15 V DC minimum/5 mA minimum OFF Voltage: 5 V DC maximum

Digital Outputs (SIO [DO] Mode)

On-Resistance: 120 m Ω typical, 250 m Ω maximum Current Limit: 0.7 A minimum, 1.0 A typical, 1.3 A maximum Off Leakage Current: -10 μ A minimum, 10 μ A maximum

Certifications



Dimensions

All measurements are listed in millimeters [inches], unless noted otherwise.







Accessories

Cordsets

5-Pin Threaded M12 Cordsets—Double Ended						
Model	Length	Style	Dimensions	Pinout (Male)	Pinout (Female)	
MQDEC-501SS	0.31 m (1.02 ft)		40 Typ		$\begin{array}{c}1\\1\\4\end{array}$	
MQDEC-503SS	0.91 m (2.99 ft)	Male Straight/	M12 x 1 J ø 14.5 J			
MQDEC-506SS	1.83 m (6 ft)	Female Straight	44 Typ. —————	4 - Decure		
MQDEC-512SS	3.66 m (12 ft)			1 = Brown 2 = White 3 = Blue	4 = Black 5 = Gray	
MQDEC-515SS	5 m (16.4 ft)					
MQDEC-530SS	9 m (29.5 ft)		ø 14.5 ⊣			
MQDEC-550SS	15 m (49.2 ft)					



4-Pin Threaded M12 Cordsets—Double Ended				
Model	Length	Style	Dimensions	Pinout
MQDEC-401SS	0.31 m (1 ft)	Male Straight/	40 Typ	Female
MQDEC-403SS	0.91 m (2.99 ft)			
MQDEC-406SS	1.83 m (6 ft)			1 (00) 2
MQDEC-412SS	3.66 m (12 ft)			4
MQDEC-420SS	6.10 m (20 ft)			Male
MQDEC-430SS	9.14 m (30.2 ft)		a 14 5 (0 57")	
MQDEC-450SS 15.2 m (49.9 ft)	Female Straight	44 Typ. (1.73) M12 x 1 ø 14.5 [0.57]		
				1 = Brown 2 = White 3 = Blue 4 = Black

4-Pin Threaded M12 Cordsets—Double Ended				
Model	Length	Style	Dimensions	Pinout
MQDEC-403RS	0.91 m (2.99 ft)		20 T	
MQDEC-406RS	1.83 m (6 ft)	Male Right-Angle/ Female Straight		
MQDEC-412RS	3.66 m (12 ft)			
MQDEC-420RS	6.10 m (20 ft)			
MQDEC-430RS	9.14 m (30.2 ft)			
MQDEC-450RS	15.2 m (49.9 ft)			
MQDEC-403RR	0.9 m (2.9 ft)			
MQDEC-406RR	1.8 m (5.9 ft)	Male Right-Angle/ Female Right-Angle		
MQDEC-412RR	3.6 m (11.8 ft)			
MQDEC-420RR	6.1 m (20 ft)			

Brackets

SMBR90S

- Stainless steel bracket
- 4x M4-07 pemnuts (B)
- Includes 2x M4 stainless steel hex head screws and flat washers

Hole center spacing: A = 40, B = 20 Hole size: A = ø 5



Maintenance and Service

Do not use alcoholic cleaning agents. The R90C 4-Port Converter is maintenance-free.

Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to:

For patent information, see www.bannerengineering.com/patents.

